


INSTALLATION INSTRUCTIONS

VISA LIGHTING
AN OLDENBURG GROUP COMPANY
1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting

Model: **ESCAPE**
Fixture Family: **OW1940PSX, OW1942PSX**
Document Description: Installation Instructions for Escape wall mount
Outdoor Escape Series Luminaires



ESCAPE

OW1940PSX
OW1942PSX

Drawing: 760839XX

Rev: A

Sheet: 1 of 2

Eng: MJB

Date Drawn: 10/10/10

! When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.


INSTALLATION INSTRUCTIONS



Model: **ESCAPE**
Fixture Family: **OW1940PSX, OW1942PSX**
Document Description: Installation Instructions for Escape wall mount
Outdoor Escape Series Luminaires

1717 West Civic Drive Milwaukee, WI 53209
414-354-6600
Design Modification Rights Reserved
© Visa Lighting

TYPICAL FIXTURE Shown oriented in the up position



- 1 Locate desired wall opening for power feed and drill 1/2" diameter hole. Locate center hole of mounting plate over power feed hole and mark for anchor locations.
- 2 Install wall anchors (by others). Attach mounting plate to wall and secure in place via flat head mounting screws (by others). **Apply silicone around back periphery of mounting plate outdoor models only!**
- 3 Connect 24 volt power feed to fixture and push back in wall.
- 4 Mount fixture to wall via mounting plate and mounting plate nuts. **Make sure sealing gaskets are in place on mounting plate and on power cord outdoor models only.**
Note: fixture may be oriented in any direction.
- 5 Install lens and lens frame.

! When using electrical equipment, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before installing and save for future use.
- Make sure all connections are in accordance with the National Electrical Code and local regulations.
- To avoid possible electric shock, be sure the power supply is turned off before servicing or installing the fixture.
- Service should be performed by qualified personnel.
- These instructions may not cover all details or variations. If additional information is needed, please contact Visa Lighting.

Drawing: 760839XX
Rev: A
Sheet: 2 of 2
Eng: MJB
Date Drawn: 10/10/10